

INSTALLING THE FOAM/SPRAY NOZZLE



1.) Gently remove existing bottle/bucket fill nozzle so locking tabs are not damaged.



2.) Make sure the lever is down in bucket fill position.



3.) Now make sure to properly align foam/spray nozzle to locking tabs on dispenser before connecting



4.) Rotate to proper icon for foam or spray



5.) Connect to the water supply and activate unit